

## KN-Q7A Drill Template – US measurements

Outside cut is 3.3 inches by 5.9 inches. The print Paper size is 8.5 inches by 11 inches.

The position of holes for feet is not as critical as the 3 holes for the transistors.

We suggest that you cut the paper template out along the lines provided and place the paper template in the case bottom to double check that the holes align properly with the Transistor Placement from the PC board.

Drill holes using a 7/64 inch drill bit or a 1/8 inch drill bit placed in center of black circles, 7 holes in total.

|----- 3.3 inches -----|  
|-----1.3 inches-----| |---- 1.25 inches-----|  
|-----| 0.4 inches

